



■ 各部位名称



※使用时，必须用选配的监控I/O用电缆。

■ 外观图

■ SR1-X/SR1-P 05・10



■ SR1-X/SR1-P 20

